


APPLICATION:

- Terminate the very flexible Zipset actuator cable in the air inlet / outlet
- Zipset actuator cable can be run inside the duct or penetrate the diffuser backpan
- Zipset actuator 8' factory wired cable can be extended using extension cables
- Optional RCB holding clip (pressure sensitive adhesive) can be installed in a convenient location in the diffuser to hold the connector after balancing



www.zipset-hvac.com

Dimensions are inches.

PROJECT:

ENGINEER:

CONTRACTOR: